

Boiler design calculation Tutorial

Boiler Design Calculation is a fundamental process in the development of efficient, safe, and reliable boiler systems used across various industries. Whether for power generation, heating applications, or process industries, proper boiler design ensures optimal performance, energy efficiency, and adherence to safety standards. This comprehensive guide delves into the essential aspects of boiler design calculation, providing insights into the methodologies, parameters, and best practices involved.

Understanding the Importance of Boiler Design Calculation

Boiler design calculation is the process of determining the optimal specifications and dimensions of a boiler to meet specific operational requirements. It involves analyzing various factors such as heat load, steam demand, fuel type, and safety considerations. Proper calculations help in:

- Ensuring the boiler can produce the required steam or hot water efficiently.
- Maintaining safety standards and preventing hazards like overpressure or explosions.
- Optimizing fuel consumption and operational costs.
- Complying with regulatory standards and codes.

Key Parameters in Boiler Design Calculation

Before starting the calculation process, it is essential to identify and understand the key parameters that influence boiler design:

1. Heat Load or Steam Demand

- Defines the amount of heat energy or steam required by the process or application.
- Usually expressed in terms of power (kW or MW) or steam flow rate (kg/hr or ton/hr).

2. Fuel Type and Heating Value

- Determines the energy content available for combustion.
- Common fuels include coal, natural gas, oil, or biomass.
- Heating value (calorific value) is expressed as gross or net calorific value (kJ/kg or MJ/m³).

3. Operating Pressure and Temperature

- Influences the boiler material selection, safety features, and design pressure.
- Typical pressures range from atmospheric to several hundred bar for power plants.

4. Feed Water Properties

- Impacts boiler material selection and water treatment requirements.
- Parameters include TDS, pH, and hardness.

5. Efficiency

- Overall efficiency depends on heat transfer, combustion, and losses.
- It affects the size and capacity calculations.

Step-by-Step Process for Boiler Design Calculation

Designing a boiler involves multiple stages, from initial data collection to detailed component design. Here is a structured approach:

1. Determining the Steam or Hot Water Load

- Calculate the total heat demand based on process requirements.
- For example, if a process requires 10,000 kg/hr of steam at 10 bar, the heat load can be computed using specific enthalpy values.

2. Calculating the Required Heating Surface Area

- The heat transfer area ensures sufficient heat exchange between combustion gases and water/steam.
- Use heat transfer equations:

$Q = U \times A \times \Delta T_{lm}$

$$Q = U \times A \times \Delta T_{lm}$$

\]

Where:

- $\dot{Q}$ = heat transfer rate (W)
- U = overall heat transfer coefficient ($\text{W/m}^2\cdot\text{K}$)
- A = heat transfer area (m^2)
- ΔT_{lm} = log mean temperature difference (K)

- Rearranged to find A :

\[

$$A = \frac{\dot{Q}}{U \times \Delta T_{lm}}$$

\]

3. Estimating the Combustion Chamber and Furnace Size

- Determine the furnace volume based on fuel combustion rate and heat release.
- Use empirical formulas or standards such as ASME or ISO.

4. Calculating the Air-Fuel Ratio

- Essential for complete combustion.
- Obtain from fuel properties and desired excess air levels.

5. Determining Flue Gas Quantities and Composition

- Calculate the amount of flue gases produced per unit of fuel burned.
- Use stoichiometry based on the fuel's chemical composition.

6. Designing the Heat Transfer Surfaces

- Decide on the number and size of tubes, fire tubes, or water tubes.

- Consider factors like heat transfer coefficient, fouling, and maintenance.

7. Safety and Pressure Components Design

- Design pressure parts such as shells, drums, and safety valves.
- Apply relevant safety codes and standards.

Common Calculations in Boiler Design

Several standard calculations are integral to boiler design, including:

1. Evaporation Rate Calculation

- Determines the amount of water converted to steam per hour.

\[

$$E = \frac{Q}{h_v}$$

\]

Where:

- E = evaporation rate (kg/hr)
- Q = heat input (kW)
- h_v = latent heat of vaporization (kJ/kg)

2. Combustion Efficiency

- Ratio of energy released by combustion to the energy supplied.

3. Heat Loss Calculations

- Includes losses through flue gases, radiation, and unburned fuels.

4. Stack Height and Diameter

- Calculated to ensure proper draft and dispersion of flue gases.

Standards and Codes in Boiler Design Calculation

Adhering to industry standards is crucial for safety and performance. Some widely recognized standards include:

- ASME Boiler and Pressure Vessel Code (BPVC)
- European Standard EN 12952/12953
- Indian Boiler Regulation (IBR)
- ISO standards related to boiler design

These standards provide guidelines for materials, safety features, testing, and calculations.

Tools and Software for Boiler Design Calculation

Modern boiler design heavily relies on computational tools and software to enhance accuracy and efficiency:

- Thermal Design Software: E.g., Thermoflow, HTRI, and ANSYS for heat transfer analysis.
- Spreadsheet Tools: Customized Excel sheets for preliminary calculations.
- CAD and Simulation Software: For detailed component design and stress analysis.

Best Practices for Accurate Boiler Design Calculation

To ensure precise and reliable calculations, consider the following:

- Use accurate and up-to-date data for fuel properties and heat transfer coefficients.
- Incorporate safety margins to account for operational variances.
- Validate calculations with empirical data or pilot testing.
- Collaborate with experienced boiler designers and engineers.
- Continually update calculations based on operational feedback.

Conclusion

Boiler design calculation is a critical process that combines thermodynamics, heat transfer, materials science, and safety standards to develop efficient and safe boiler systems. Proper calculations lead to optimized performance, reduced operational costs, and compliance with safety

regulations. Whether designing a small industrial boiler or a large power plant unit, a systematic and meticulous approach to boiler design calculation is essential for success. Leveraging modern tools, adhering to standards, and applying best practices will ensure that your boiler system meets the demands of your application reliably and efficiently.

Boiler Design Calculation: A Comprehensive Guide for Engineers and Designers

Designing an efficient and safe boiler system requires meticulous calculation and understanding of multiple parameters. Boiler design calculation is a critical aspect of thermal engineering, ensuring that the boiler operates reliably under specified conditions, meets safety standards, and achieves optimal performance. This detailed review explores the core concepts, methodologies, and practical considerations involved in boiler design calculations.

Introduction to Boiler Design Calculation

Boiler design calculation involves determining the appropriate dimensions, materials, and operating parameters of a boiler to generate steam or hot water efficiently while maintaining safety and compliance with standards. It encompasses various aspects including heat transfer, pressure considerations, material selection, and operational efficiency.

The primary goals of boiler design calculation are:

- To determine the required heat transfer surface area.
- To ensure the boiler can produce the desired steam output.
- To maintain safe operating pressures and temperatures.
- To optimize fuel consumption and minimize emissions.
- To adhere to safety codes and standards such as ASME, IBR, and other regional regulations.

Fundamental Principles of Boiler Design

Understanding the basic principles is essential before diving into detailed calculations:

1. Heat Transfer

- Heat transfer occurs via conduction, convection, and radiation.
- The boiler must transfer heat from combustion gases to water/steam efficiently.
- Calculations involve determining heat transfer coefficients and surface areas.

2. Thermodynamic Considerations

- The Rankine cycle principles govern the conversion of water into steam.
- Key parameters include inlet/outlet pressures, temperatures, and enthalpy changes.

3. Material Strength and Safety

- The boiler's materials must withstand internal pressure and temperature.
- Calculations include stress analysis and safety margins.

4. Fluid Dynamics

- Flow rates of gases and liquids influence heat transfer and pressure drops.
- Proper design minimizes flow-induced vibrations and erosion.

Key Calculations in Boiler Design

Design calculations are iterative and interconnected. The core calculations include:

1. Steam Generation Rate (Q)

- Determines the total heat energy required to produce the desired steam output.
- Calculated as:

$$Q = m \times (h_{\text{steam}} - h_{\text{feedwater}})$$

where:

- Q = heat duty (kW or BTU/hr)
- m = mass flow rate of steam (kg/hr or lb/hr)
- h_{steam} = enthalpy of steam at desired conditions
- $h_{\text{feedwater}}$ = enthalpy of feedwater

2. Heat Transfer Surface Area (A)

- Critical for ensuring the boiler transfers heat efficiently.
- Calculated based on heat transfer equations:

[

$$Q = U \times A \times \Delta T_{lm}$$

]

where:

- U = overall heat transfer coefficient
- ΔT_{lm} = log mean temperature difference

- Rearranged to find A :

[

$$A = \frac{Q}{U \times \Delta T_{lm}}$$

]

- Factors influencing U include combustion efficiency, fouling, and material properties.

3. Combustion and Fuel Calculation

- Determines fuel requirements to produce the needed heat.
- Based on the calorific value of fuel (e.g., coal, oil, gas):

[

$$\text{Fuel needed} = \frac{Q}{\text{Calorific value} \times \text{Efficiency}}$$

]

- Considerations:

- Combustion air requirements.
- Excess air for complete combustion.

4. Pressure Drop Calculations

- Ensures fluid flows smoothly without excessive pressure losses.
- Calculated for:
 - Flue gases in the combustion chamber.
 - Water/steam flow in tubes.
 - Feedwater inlet and outlets.
- Typical methods involve Darcy-Weisbach or empirical correlations.

5. Boiler Shell and Drum Design

- The drum and shell thickness are determined based on internal pressure, material strength, and safety margins.
- Use formulas from pressure vessel codes:

\[

$$t = \frac{P \times r}{2 \times S \times E}$$

\]

where:

- t = wall thickness
- P = internal pressure
- r = internal radius
- S = allowable stress
- E = joint efficiency

Design Considerations for Different Types of Boilers

Different boiler types require specific design considerations:

1. Fire Tube Boilers

- Suitable for low to medium pressures.
- Design focuses on tube material strength, water circulation, and heat transfer.

2. Water Tube Boilers

- Used for high-pressure applications.
- Emphasizes proper tube layout, water flow rates, and stress analysis due to high internal pressures.

3. Electric Boilers

- Simpler in design but require calculations for electrical input, heating element placement, and insulation.

Materials Selection in Boiler Design

The choice of materials impacts safety, durability, and efficiency:

- Common materials include carbon steel, alloy steels, stainless steels.
- Material properties considered:
 - Tensile strength
 - Corrosion resistance
 - Thermal conductivity
 - Weldability

Design calculations ensure that selected materials can withstand operating stresses and temperatures.

Safety and Regulatory Compliance

Safety is paramount in boiler design:

- Compliance with standards such as ASME Boiler and Pressure Vessel Code, IBR, and other regional regulations.

- Calculations for:
- Maximum allowable working pressure (MAWP).
- Safety margins.
- Thickness calculations for pressure parts.
- Relief valve sizing.

Regular safety checks and non-destructive testing (NDT) are integral to the design process.

Practical Steps in Boiler Design Calculation

A typical workflow includes:

- Define Requirements
- Steam output (mass flow rate).
- Operating pressure and temperature.
- Fuel type and calorific value.
- Determine Heat Duty
- Based on process needs and efficiencies.
- Calculate Combustion Air Requirements
- Using fuel properties and excess air considerations.
- Estimate Heat Transfer Surface Area
- Using heat transfer equations and empirical data.
- Design Combustion Chamber and Flue Gas Path

- Optimize for heat transfer and minimize emissions.
- Size Pressure Parts
- Shell, drum, tubes, headers based on internal pressures.
- Ensure Safety and Compliance
- Thickness calculations and safety margins.
- Review and Iterate
- Adjust parameters based on practical constraints and safety margins.

Advanced Topics in Boiler Design Calculation

For complex or high-capacity boilers, advanced calculations involve:

- Computational Fluid Dynamics (CFD) for flow and heat transfer analysis.
- Finite Element Analysis (FEA) for stress and fatigue analysis.
- Optimization algorithms for improving efficiency and reducing costs.
- Emission control calculations, especially with strict environmental standards.

Conclusion

Boiler design calculation is a multidisciplinary task that combines thermodynamics, fluid mechanics, material science, and safety engineering. Accurate calculations ensure that boilers operate safely, efficiently, and reliably under specified conditions. Modern design practices incorporate computational tools and adherence to standards, but fundamental principles remain rooted in sound engineering calculations.

Properly executed boiler design calculations not only optimize operational performance but also safeguard personnel and equipment, making them indispensable in thermal engineering projects. Whether designing a small industrial boiler or a high-pressure power plant boiler, a systematic,

detail-oriented approach is essential for success.

In summary, boiler design calculation is a complex but essential process that requires a thorough understanding of heat transfer, fluid flow, material properties, and safety standards. By carefully analyzing each aspect and iterating through calculations, engineers can develop boilers that meet operational requirements efficiently and safely for years to come.

Question What are the key parameters to consider in boiler design calculations? Key parameters include the steam capacity, pressure and temperature requirements, fuel type, heat transfer surfaces, materials, and safety standards to ensure efficient and safe operation. How is the heat transfer area calculated in boiler design? The heat transfer area is calculated based on the required heat transfer rate, the overall heat transfer coefficient, and the temperature difference between the hot gases and the water/steam, using the formula: $A = Q / (U \Delta T)$. What role does combustion efficiency play in boiler design calculations? Combustion efficiency impacts fuel consumption and heat transfer; accurate calculations ensure optimal burner design and fuel utilization, minimizing emissions and operational costs. How do pressure and temperature limits influence boiler component design? Pressure and temperature limits determine material selection, wall thickness, and safety features, ensuring the boiler can withstand operating conditions without failure. What are the typical methods used for calculating boiler drum size? Methods include considering steam generation rate, water circulation requirements, and separation efficiency, often using empirical formulas and standards like ASME codes to determine appropriate drum dimensions. How does flue gas analysis impact boiler design calculations? Flue gas analysis informs heat exchange efficiency and emission control strategies, influencing the design of economizers, air preheaters, and flue gas pathways. What safety factors are incorporated in boiler design calculations? Safety factors account for material strength, corrosion, thermal expansion, and operational uncertainties, ensuring compliance with safety standards and preventing failures. Why is it important to perform thermal stress analysis during boiler design? Thermal stress analysis helps identify potential failure points due to temperature gradients, allowing for design modifications that prevent cracks or deformation during operation.

Related keywords: boiler efficiency, heat transfer analysis, pressure vessel design, combustion calculation, thermal stress analysis, fluid flow modeling, material selection, energy balance, sizing calculations, safety standards

Economiser Design Calculation

Economiser design calculation is a critical process in the field of thermal engineering, especially when it comes to optimizing the efficiency of heating systems such as boilers, steam generators,

and other thermal equipment. An economizer is a heat exchange device that preheats feedwater using residual heat from flue gases, thereby reducing fuel consumption and improving overall system efficiency. Proper design calculations are essential to ensure that the economizer performs optimally, safely, and economically. This article provides a comprehensive overview of economiser design calculation, covering fundamental concepts, essential parameters, step-by-step procedures, and important considerations to achieve an efficient and reliable economizer design.

Understanding the Basics of Economiser Design Calculation

Before diving into the detailed calculations, it is vital to understand what an economizer is and its role in thermal systems.

What is an Economizer?

An economizer is a heat exchanger that captures waste heat from flue gases to preheat feedwater before it enters the boiler or combustion chamber. This process enhances the thermal efficiency by reducing the amount of fuel needed to generate the desired steam or hot water.

Why is Economiser Design Calculation Important?

Accurate design calculations ensure:

- Optimal heat transfer efficiency
- Minimized pressure drops
- Prevention of corrosion and overheating
- Economic operation with minimized fuel consumption
- Longevity and safety of the equipment

Key Parameters in Economiser Design Calculation

Effective designing involves determining several parameters that influence the heat transfer process, mechanical design, and operational safety.

1. Hot and Cold Flu Gas Temperatures

- **Inlet flue gas temperature (T_{hot_in}):** Temperature of gases leaving the furnace.
- **Outlet flue gas temperature (T_{hot_out}):** Temperature after heat transfer.
- **Feedwater inlet temperature (T_{cold_in}):** Usually the feedwater temperature entering the economizer.

- **Preheated water temperature (T_cold_out):** Water temperature after heat exchange.

2. Heat Duty (Q)

The amount of heat transferred from flue gases to feedwater, typically expressed in kW or Btu/hr.

3. Heat Transfer Area (A)

The total surface area available for heat exchange, which is a function of tube size, length, and layout.

4. Overall Heat Transfer Coefficient (U)

Represents combined heat transfer capabilities, considering convection, conduction, and fouling effects.

5. Flue Gas Flow Rate (m_g)

Mass flow rate of flue gases passing through the economizer.

6. Feedwater Flow Rate (m_f)

Mass flow rate of water supplied to the economizer.

Step-by-Step Economiser Design Calculation

Designing an economizer involves systematic calculations to determine its size, material, and operational parameters.

Step 1: Determine the Heat Duty (Q)

The primary calculation involves establishing the heat transfer required.

- Equation:

$$Q = m_f \times C_{p_f} \times (T_{\text{cold_out}} - T_{\text{cold_in}})$$

Where:

- C_{p_f} = specific heat capacity of feedwater (kJ/kg·K)
- T_{cold_in} = inlet feedwater temperature
- T_{cold_out} = preheated feedwater temperature

Example:

Suppose feedwater flow rate is 10,000 kg/hr, $C_{p_f} = 4.2$ kJ/kg·K, $T_{cold_in} = 30^\circ\text{C}$, $T_{cold_out} = 150^\circ\text{C}$.

$$Q = (10,000/3600) \text{ kg/sec} \times 4.2 \text{ kJ/kg}\cdot\text{K} \times (150 - 30) \text{ K} = 116.67 \text{ kW}$$

Step 2: Establish Flue Gas Outlet Temperature (T_{hot_out})

Typically, flue gases exit at a temperature that balances heat transfer efficiency and pollution control standards, often around 150-250°C.

Step 3: Calculate the Log Mean Temperature Difference (LMTD)

LMTD is used to evaluate the heat exchanger's driving temperature difference.

- For counter-flow heat exchangers:

$$\text{LMTD} = [(T_{hot_in} - T_{cold_out}) - (T_{hot_out} - T_{cold_in})] / \ln[(T_{hot_in} - T_{cold_out}) / (T_{hot_out} - T_{cold_in})]$$

Example:

$$T_{hot_in} = 250^\circ\text{C}, T_{hot_out} = 150^\circ\text{C}, T_{cold_in} = 30^\circ\text{C}, T_{cold_out} = 150^\circ\text{C}.$$

$$\text{LMTD} = [(250 - 150) - (150 - 30)] / \ln[(250 - 150) / (150 - 30)] = (100 - 120) / \ln(100/120) = -20 / (-0.182) = 109.89^\circ\text{C}$$

(Note: Use absolute values; negative signs indicate heat flow direction.)

Step 4: Determine Overall Heat Transfer Coefficient (U)

Estimate U based on typical values or through detailed calculations considering convection and fouling.

- Typical U values:
- For gases: 20-40 W/m²·K
- For water/steam: 500-800 W/m²·K

Assuming U = 100 W/m²·K for a well-maintained economizer.

Step 5: Calculate Required Heat Transfer Area (A)

Using the heat transfer equation:

$$Q = U \times A \times \text{LMTD}$$

Rearranged:

$$A = Q / (U \times \text{LMTD})$$

Convert U to consistent units (W/m²·K):

$$U = 100 \text{ W/m}^2\cdot\text{K}$$

$$Q = 116,670 \text{ W (from example calculation)}$$

$$A = 116,670 / (100 \times 109.89) \approx 116,670 / 10,989 \approx 10.61 \text{ m}^2$$

This is the approximate heat transfer surface area needed.

Step 6: Mechanical Design and Tube Sizing

Based on the area, select tube dimensions:

- Tube diameter (d)
- Tube length (L)
- Number of tubes (N)

For example, choosing tubes of 25 mm diameter, the number of tubes:

$$N = A / (\pi \times d \times L)$$

Assuming tube length L = 3 m:

$$N = 10.61 / (\pi \times 0.025 \times 3) \approx 10.61 / (0.2356) \approx 45 \text{ tubes}$$

Design considerations include ensuring proper spacing, flow distribution, and ease of maintenance.

Important Considerations in Economiser Design Calculation

While performing calculations, engineers must account for various factors to optimize performance and safety.

1. Fouling and Corrosion

Fouling reduces heat transfer efficiency; hence, selecting materials resistant to corrosion and fouling is critical.

2. Pressure Drop

Excessive pressure drops reduce system efficiency and increase fan or pump energy costs. Design should minimize pressure losses.

3. Material Selection

Materials must withstand high temperatures, corrosion, and thermal expansion.

4. Safety and Codes

Design must adhere to safety standards, pressure vessel codes, and environmental regulations.

Advanced Topics in Economiser Design Calculation

For complex systems, additional calculations and considerations are necessary:

1. Thermal Stress Analysis

Evaluate stress due to temperature gradients.

2. Fin and Tube Design

Optimize heat transfer surfaces with fins for enhanced efficiency.

3. Dynamic Simulation

Use software tools for simulating transient behaviors and optimizing design.

Conclusion

An effective **economiser design calculation** hinges on understanding the heat transfer principles, accurately estimating key parameters, and carefully balancing thermal efficiency with mechanical and operational constraints. By systematically following the outlined steps—calculating heat duty, temperature differences, heat transfer area, and considering material and fouling effects—designers can develop economizers that significantly improve boiler efficiency, reduce fuel costs, and ensure long-term operational reliability. Staying updated with industry standards and utilizing advanced simulation tools further enhances the precision and performance of economizer designs, making them indispensable components in modern thermal systems.

Keywords: economiser design calculation, heat transfer, boiler efficiency, heat exchanger design, thermal engineering, heat transfer area, overall heat transfer coefficient, flue gases, feedwater preheating, heat exchanger calculation

Economiser Design Calculation: Unlocking Efficiency in Industrial Heat Recovery

Introduction

Economiser design calculation is a critical step in optimizing thermal systems, particularly in industries where energy efficiency and cost savings are paramount. An economiser, often regarded as an integral component of boilers and heat recovery systems, serves to preheat feedwater using residual heat from flue gases, thereby reducing fuel consumption and operational costs. As industries strive toward sustainable operations, understanding the nuances of economiser design calculations becomes essential for engineers, plant operators, and energy managers alike. This article delves into the fundamentals of economiser design calculation, exploring its importance, methodology, and practical considerations to facilitate efficient and effective heat recovery solutions.

The Significance of Economiser Design Calculation

Before diving into the technicalities, it's vital to comprehend why precise calculation is indispensable. Proper economiser design ensures:

- **Enhanced Thermal Efficiency:** Properly designed economisers reclaim maximum heat, minimizing energy wastage.
- **Fuel Cost Reduction:** Preheating feedwater reduces the fuel required for boiler operation.
- **Operational Reliability:** Accurate calculations prevent issues like thermal stresses, corrosion, and fouling.

- Environmental Benefits: Reduced fuel consumption leads to lower emissions, aligning with sustainability goals.

An ill-designed economiser may lead to increased maintenance costs, reduced lifespan, or even system failure. Therefore, a systematic approach to calculation is crucial for optimal performance.

Fundamental Principles Underpinning Economiser Design

Economiser design calculation hinges on thermodynamic principles and heat transfer fundamentals. The key elements include:

- Heat Transfer Mechanisms: Conduction, convection, and radiation govern heat exchange between flue gases and feedwater.
- Mass and Energy Balances: Ensuring the conservation of energy across the system.
- Material Considerations: Selecting materials that withstand high temperatures and corrosive environments.
- Flow Dynamics: Ensuring proper fluid flow to maximize heat transfer without causing excessive pressure drops.

Understanding these principles provides the foundation for accurate and efficient economiser design.

Step-by-Step Approach to Economiser Design Calculation

Designing an economiser involves several sequential steps, each requiring detailed analysis and precise data. Below is a comprehensive guide:

- Define System Parameters and Operating Conditions

Begin by gathering essential data:

- Flue Gas Properties: Temperature, composition, velocity, and flow rate.
- Feedwater Properties: Temperature, flow rate, and specific heat capacity.
- Boiler Load and Efficiency: To determine heat demand.
- Space Constraints: Physical dimensions available for the economiser.
- Material Constraints: Compatibility with high-temperature gases and corrosive elements.

Accurate data collection at this stage ensures meaningful calculations downstream.

- Calculate Heat Duty (Q)

Determine the heat transfer requirement:

$$Q = m_{\text{feedwater}} \times C_{p_{\text{feedwater}}} \times (T_{\text{out}} - T_{\text{in}})$$

Where:

- Q = Heat duty (kW or Btu/hr)
- $m_{\text{feedwater}}$ = Mass flow rate of feedwater (kg/s or lb/hr)
- $C_{p_{\text{feedwater}}}$ = Specific heat capacity of feedwater (kJ/kg·K or Btu/lb·°F)
- T_{out} = Desired feedwater temperature after preheating
- T_{in} = Feedwater inlet temperature (usually ambient or condenser temperature)

This value guides the sizing of the economiser.

- Determine Flue Gas Exit Temperature ($T_{\text{gas_out}}$)

Estimate the temperature of flue gases after passing through the economiser:

$$T_{\text{gas_out}} = T_{\text{gas_in}} - \Delta T$$

Where ΔT (temperature drop) depends on the heat transfer efficiency. Typical flue gas exit temperatures are maintained to prevent corrosion and fouling?often around 150°C (300°F), but specific values depend on operational parameters.

- Establish Heat Transfer Area (A)

Using the overall heat transfer coefficient (U) and temperature difference, calculate the required heat transfer area:

$$Q = U \times A \times \Delta T_{\text{lm}}$$

Where:

- ΔT_{lm} = Log Mean Temperature Difference (LMTD)
- U = Overall heat transfer coefficient, which accounts for conduction, convection, and fouling

resistances.

Rearranged:

$$A = Q / (U \times \Delta T_{lm})$$

This step involves calculating the LMTD, which accounts for the temperature differences on both sides of the economiser.

Deep Dive: Calculating Log Mean Temperature Difference (LMTD)

LMTD is essential for determining the effective temperature driving force for heat transfer:

$$\Delta T_1 = T_{\text{gas_in}} - T_{\text{feedwater_out}}$$

$$\Delta T_2 = T_{\text{gas_out}} - T_{\text{feedwater_in}}$$

Then,

$$LMTD = (\Delta T_1 - \Delta T_2) / \ln(\Delta T_1 / \Delta T_2)$$

This value reflects the average temperature difference experienced by the heat exchange surface.

- Material and Structural Design Considerations

Once the heat transfer area is established, the next step involves designing the physical structure:

- Tube Selection: Material (e.g., stainless steel, carbon steel) based on temperature and corrosion resistance.

- Tube Arrangement: U-tube, straight tube, or other configurations for optimal flow and maintenance.

- Fouling Factors: Incorporate allowances for fouling, which reduces heat transfer over time.

- Pressure Drop: Calculate to ensure it remains within acceptable limits, avoiding excessive pumping power.

Designing for ease of maintenance, accessibility, and durability is equally critical.

- Finalizing the Design and Validation

With preliminary dimensions and configurations established, validation involves:

- Simulation and Modelling: Use computational tools to simulate heat transfer and fluid flow.
- Prototype Testing: For large or complex systems, prototype testing can reveal practical issues.
- Performance Analysis: Ensure the design meets the targeted heat recovery and efficiency goals.

Iterative refinement ensures that the economiser delivers optimal performance over its operational lifespan.

Practical Considerations and Challenges

While calculations provide a theoretical framework, real-world applications often entail challenges:

- Fouling and Corrosion: Regular maintenance and material choice are vital to prevent efficiency loss.
- Space Limitations: Physical constraints may necessitate compact designs.
- Variable Operating Conditions: Fluctuations in flue gas properties require flexible and adaptable designs.
- Cost-Benefit Analysis: Balancing initial investment with long-term savings involves economic assessment.

Addressing these factors ensures that the economiser performs reliably and economically.

Conclusion

Economiser design calculation is a nuanced process that combines thermodynamics, heat transfer principles, material science, and practical engineering. Accurate calculations underpin the successful implementation of economisers, enabling industries to achieve significant energy savings, reduce emissions, and operate more sustainably. As energy efficiency standards become more stringent worldwide, mastering the art of economiser design calculation will remain a vital skill for engineers committed to advancing thermal system performance. By following a systematic approach?defining parameters, calculating heat duties, determining transfer areas, and considering practical constraints?professionals can craft economisers that stand the test of time, delivering maximum efficiency with minimal operational issues.

Question What are the key parameters involved in economiser design calculation? The key parameters include flue gas temperature, exhaust gas flow rate, feedwater inlet and outlet temperatures, heat transfer surface area, and the overall heat transfer coefficient. **Answer** How is the heat

transfer rate calculated in an economiser? The heat transfer rate is calculated using the formula $Q = m C_p \Delta T$, where m is the mass flow rate of flue gases or water, C_p is the specific heat capacity, and ΔT is the temperature difference between inlet and outlet streams. What is the significance of the heat transfer coefficient in economiser design? The heat transfer coefficient determines the efficiency of heat exchange between flue gases and water; higher coefficients lead to better heat transfer and more efficient economiser performance. How do you determine the surface area required for an economiser? The surface area is determined by rearranging the heat transfer equation: $A = Q / (U \Delta T_{lm})$, where Q is the heat transfer rate, U is the overall heat transfer coefficient, and ΔT_{lm} is the log mean temperature difference. What are common materials used in economiser construction, and how do they affect design calculations? Materials such as stainless steel, carbon steel, and alloy steels are common. Material choice affects the overall heat transfer coefficient, corrosion resistance, and thermal expansion, which must be considered in the design calculations. How does flue gas velocity impact economiser performance and design? Higher flue gas velocities increase heat transfer but can lead to erosion and pressure drops. Design must balance velocity to optimize heat transfer while minimizing wear and operational costs. What are the typical steps involved in performing an economiser design calculation? The steps include determining inlet and outlet temperatures, calculating the heat duty, selecting appropriate materials, estimating the heat transfer coefficients, calculating the required surface area, and verifying pressure drops and mechanical stability.

Related keywords: energy efficiency, heat exchanger, thermal performance, heat transfer, design optimization, fluid flow, heat load calculation, insulation, temperature difference, system integration

Read the full article online: [Economiser Design Calculation](#)

Thermal power plant heat mass balance

Thermal Power Plant Heat Mass Balance

Understanding the heat and mass balance in a thermal power plant is essential for optimizing efficiency, reducing fuel consumption, and minimizing environmental impact. The heat and mass balance analysis provides a detailed overview of how energy and materials flow through the plant, revealing opportunities for improvement and ensuring safe, reliable operation. In this article, we delve into the fundamental concepts of heat and mass balance in thermal power plants, exploring their components, significance, and how they are calculated and applied in real-world scenarios.

Introduction to Thermal Power Plant Heat and Mass Balance

A thermal power plant converts heat energy from fuel combustion into electrical energy. To achieve this conversion efficiently, it is crucial to understand how energy and mass flow through the system. The heat and mass balance approach involves quantifying the inputs, outputs, and losses within the plant to maintain an optimal operating condition.

Fundamentals of Heat and Mass Balance

What is Heat Balance?

Heat balance refers to the accounting of heat energy entering and leaving the system. It ensures that the total heat supplied equals the heat used for steam generation, plus losses due to various factors such as radiation, convection, and conduction.

What is Mass Balance?

Mass balance involves tracking the flow of mass—mainly water, steam, and combustion gases—throughout the plant. It ensures the mass input equals the mass output when considering accumulation and losses.

Components of Heat and Mass Balance in a Thermal Power Plant

1. Fuel Combustion

- The primary heat source, typically coal, oil, or natural gas.
- Combustion process releases heat energy which is transferred to water/steam cycle.
- Key parameters:
 - Calorific value of fuel
 - Air-fuel ratio
 - Mass of fuel combusted

2. Boiler and Steam Generation

- Converts water into high-pressure steam.
- Heat transfer occurs via combustion gases passing over water tubes.
- Key parameters:

- Steam flow rate
- Steam pressure and temperature
- Efficiency of heat transfer

3. Turbine and Power Generation

- High-pressure steam drives turbines, producing mechanical and electrical energy.
- Efficiency depends on steam conditions and turbine design.
- Important considerations:

- Mass flow of steam
- Enthalpy change in the turbine
- Mechanical losses

4. Condenser and Cooling

- Condenses exhaust steam back into water for reuse.
- Cooling water absorbs residual heat.
- Key points:

- Cooling water flow rate
- Heat rejected to cooling system
- Cooling efficiency

5. Flue Gas and Ash Handling

- Combustion gases carry away heat and pollutants.
- Ash disposal involves handling solid residues.
- Considerations:

- Mass flow of flue gases
- Pollutant removal efficiency
- Mass of ash produced

Steps to Calculate Heat and Mass Balance in a Thermal Power Plant

1. Data Collection

- Gather data on fuel calorific value, steam parameters, flow rates, temperatures, pressures, and efficiencies.

2. Determine Fuel Input

- Calculate the total heat energy supplied by the fuel:
- Fuel mass flow rate $\times$ calorific value

3. Heat Distribution in the System

- Calculate heat transferred to:
 - Steam in the boiler (latent and sensible heat)
 - Auxiliary systems
 - Heat losses through flue gases, radiation, and convection

4. Steam and Water Mass Balance

- Quantify:
 - Mass of water fed into the boiler
 - Mass of steam generated
 - Condensate returned to the boiler

5. Power Output and Efficiency Calculation

- Determine the work output:
 - Based on enthalpy difference across the turbine

- Calculate thermal efficiency:
- Electrical Power Output / Heat Input from fuel

Significance of Heat and Mass Balance Analysis

- Optimization of Efficiency: Identifies energy losses and areas for improvement.
- Environmental Compliance: Helps control pollutant emissions by understanding flue gas composition.
- Cost Reduction: Enables better fuel utilization and operational cost management.
- Operational Safety: Ensures safe handling of combustion gases and residues.
- Design Improvement: Assists in designing more efficient boilers, turbines, and cooling systems.

Practical Applications and Examples

- Boiler Efficiency Calculation: Using heat input and steam output data to determine thermal efficiency.
- Flue Gas Analysis: Measuring flue gases to estimate unburned fuel and excess air.
- Ash Management: Quantifying ash produced to optimize disposal or reuse.
- Cooling Water Balance: Ensuring adequate cooling water flow and heat rejection capacity.

Tools and Techniques for Heat and Mass Balance Calculation

- Energy Balance Equations: Based on the first law of thermodynamics.
- Mass Balance Equations: Based on the conservation of mass principle.
- Process Simulation Software: Such as ASPEN Plus, HYSYS, or custom spreadsheets.
- Experimental Data and Instrumentation: Flow meters, temperature sensors, gas analyzers.

Challenges in Heat and Mass Balance Analysis

- Incomplete or inaccurate data can lead to errors.
- Variability in fuel quality and operating conditions.
- Complex interactions between system components.
- Need for continuous monitoring and updating of data.

Conclusion

A comprehensive understanding of the thermal power plant heat and mass balance is vital for ensuring optimal operation, improving efficiency, and reducing environmental impact. By systematically analyzing the energy and material flows through detailed calculations and measurements, plant operators and engineers can make informed decisions to enhance performance. As technology advances, sophisticated tools and real-time monitoring systems further support precise heat and mass balance analysis, paving the way for smarter, cleaner, and more efficient power generation.

Key Takeaways:

- Heat and mass balance analysis is fundamental to thermal power plant operation.
- It involves quantifying fuel input, heat transfer, steam generation, and losses.
- Proper analysis leads to improved efficiency, reduced costs, and environmental compliance.
- Continuous data collection and advanced tools enhance accuracy and operational insight.

Further Reading:

- Thermodynamics and Heat Transfer Principles in Power Plants
- Energy Management and Optimization in Power Systems
- Environmental Impact Assessment of Thermal Power Plants

Thermal Power Plant Heat Mass Balance: An In-Depth Analysis

Understanding the thermal power plant heat mass balance is fundamental to optimizing the efficiency and performance of thermal power stations. This concept involves the detailed accounting of energy inputs, outputs, and transformations within the plant, ensuring that each component operates at its maximum potential while minimizing losses. A comprehensive heat and mass balance allows engineers and operators to identify inefficiencies, troubleshoot issues, and plan for upgrades or maintenance with precision. As thermal power plants remain a cornerstone of global electricity generation, particularly in regions where fossil fuels dominate, grasping this balance is essential for sustainable and cost-effective operation.

Introduction to Heat and Mass Balance in Thermal Power Plants

A thermal power plant converts heat energy, primarily from burning fossil fuels like coal, oil, or natural gas, into electrical energy. The process involves multiple interconnected systems: boilers, turbines, condensers, cooling systems, and generators. Central to their efficient operation is the concept of heat and mass balance—quantitatively tracking how energy and mass flow through each component.

Heat balance involves understanding how much heat is supplied, how much is converted into useful work, and how much is lost to the surroundings. Mass balance ensures the conservation of mass within the system, accounting for fuel input, ash and flue gases, cooling water, and other by-products. Both balances are essential in analyzing plant performance, reducing emissions, and improving overall efficiency.

Fundamentals of Heat Balance in a Thermal Power Plant

Energy Input and Conversion

The primary energy input in a thermal power plant is the chemical energy stored in the fuel. This energy is transferred to the boiler, where combustion generates heat. The heat then produces high-pressure steam that drives turbines connected to generators, producing electricity.

- Key Parameters:
- Heat rate: The amount of fuel energy required to produce a unit of electricity.
- Thermal efficiency: The ratio of useful electrical energy output to the total heat input.

Heat Losses and Inefficiencies

Not all heat from combustion is converted into electrical energy; significant portions are lost through various pathways:

- Flue gases carry away a large fraction of heat.
- Heat is lost through boiler and turbine surfaces.
- Cooling water discharge absorbs residual heat.
- Mechanical and electrical losses in the generator.

Quantifying these losses through heat balance calculations helps identify areas for efficiency improvements.

Components of Heat Balance Calculation

A typical heat balance involves calculations at each stage:

- Fuel heating value: The energy content of the fuel (e.g., calorific value).
- Heat supplied to boiler: Combustion heat plus any auxiliary heat.
- Steam generation: Conversion of heat into sensible and latent heat of steam.

- Work output: Mechanical energy from turbines.
- Heat rejected: To cooling systems and surroundings.

Mass Balance in a Thermal Power Plant

Fuel and Combustion Products

Mass balance begins with the input of fuel, which contains specific amounts of carbon, hydrogen, sulfur, etc. During combustion, these elements convert into various products:

- Carbon forms CO_2 .
- Hydrogen forms H_2O .
- Sulfur forms SO_2 or SO_3 depending on combustion conditions.

Accurate measurement of fuel input and flue gases allows for the calculation of emissions and pollutant control measures.

Cooling Water and Waste Streams

Cooling water absorbs heat from condensers and is typically circulated in a closed or open loop:

- In a closed loop, water is recirculated with minimal losses.
- In an open loop, water is discharged after heat absorption, necessitating treatment and environmental considerations.

Mass balance calculations ensure that water usage, losses, and treatment requirements are well-understood.

Ash and Solid Waste Management

Combustion produces ash and other solid wastes:

- Fly ash (fine particles carried with flue gases).
- Bottom ash (collected at the bottom of the furnace).

Mass balance helps in determining the quantity of waste generated and planning for disposal or utilization.

Tools and Methods for Performing Heat and Mass Balance

Data Collection and Measurement

Accurate data collection is the backbone of effective heat and mass balance:

- Fuel flow rates.
- Temperature and pressure at various points.
- Flue gas composition.
- Cooling water flow and temperature.
- Ash and waste quantities.

Balance Calculations and Software

Engineers utilize:

- Manual calculations based on thermodynamic equations.
- Specialized software (e.g., EES, Aspen Plus, Thermo-Flow) for complex simulations.

These tools help model plant performance, predict outcomes of modifications, and optimize operations.

Importance of Assumptions and Standards

When performing balances, assumptions regarding combustion efficiency, heat losses, and measurement accuracy must be carefully validated against standards such as ISO 5167 or ASME guidelines.

Advantages of Conducting a Heat Mass Balance

- Efficiency Optimization: Identifies energy losses and opportunities for improvement.
- Emissions Control: Helps in calculating pollutants and designing control systems.
- Operational Reliability: Detects abnormal performance and potential failures.
- Cost Savings: Reduces fuel consumption and operational costs.
- Environmental Compliance: Ensures adherence to environmental regulations.

Challenges and Limitations

While heat and mass balances are invaluable, they come with certain limitations:

- Measurement Uncertainty: Inaccurate measurements can lead to erroneous balances.
- Dynamic Conditions: Variations in load, fuel quality, and ambient conditions complicate steady-state assumptions.
- Complex Interactions: Interactions between components can make simplified models less accurate.
- Data Availability: Some parameters may not be readily measurable.

Case Studies & Practical Applications

Improving Thermal Efficiency

A coal-fired thermal power plant conducted a heat balance analysis and identified that flue gas heat loss was higher than typical levels. By installing economizers and improving insulation, the plant reduced heat losses by 5%, resulting in a measurable increase in efficiency and fuel savings.

Emission Reduction Strategies

Mass balance calculations of sulfur dioxide emissions enabled a plant to optimize limestone injection in flue gas desulfurization units, reducing SO₂ emissions by 30% while maintaining economic viability.

Waste Management Optimization

Analyzing the ash mass flow allowed a plant to explore ash utilization options, such as in cement manufacturing, turning waste into a revenue-generating byproduct.

Future Trends and Innovations

- Integration with Digital Twin Technologies: Real-time heat and mass balance monitoring for predictive maintenance.
- Advanced Sensor Technologies: Improved accuracy and data collection.
- Waste Heat Recovery Systems: Enhanced heat utilization reduces losses significantly.
- Environmental Impact Modeling: More comprehensive balances considering lifecycle emissions.

Conclusion

The thermal power plant heat mass balance is a vital analytical tool that underpins efficient,

sustainable, and environmentally compliant operation of thermal power stations. By systematically accounting for energy and mass flows, engineers can pinpoint inefficiencies, optimize performance, and minimize environmental impact. While challenges remain in measurement accuracy and dynamic operation, advancements in technology and methodology continue to enhance the precision and utility of heat and mass balances. As the energy landscape evolves, mastering these balances will remain essential for the modernization and sustainability of thermal power generation.

Features of Heat and Mass Balance in Thermal Power Plants:

- Facilitates performance optimization.
- Supports environmental compliance.
- Aids in troubleshooting and maintenance.
- Enables strategic planning for upgrades.
- Enhances understanding of plant dynamics.

Pros:

- Improved plant efficiency.
- Reduced operational costs.
- Better emission control.
- Data-driven decision-making.

Cons:

- Requires accurate measurement systems.
- Can be complex for large plants.
- Time-consuming initial setup.
- Potentially affected by measurement uncertainties.

Through diligent application of heat and mass balance principles, thermal power plants can achieve higher efficiencies, lower emissions, and greater economic viability, ensuring their continued role in global energy systems.

Question What is the purpose of conducting a heat and mass balance in a thermal power plant? The purpose is to analyze the energy flow and material flow within the plant to optimize efficiency, identify energy losses, and ensure proper operation of components such as boilers, turbines, and condensers. **Answer** What are the main components involved in a thermal power plant heat mass balance calculation? The main components include the boiler, turbine, condenser, feedwater

system, and cooling system. The calculation considers heat input from fuel, heat transfer to steam, work output, and heat losses to the environment. How do you perform a heat balance calculation for a thermal power plant? You start by determining the heat input from fuel combustion, then calculate heat transfer to the steam, mechanical work done by the turbine, heat rejected in the condenser, and account for losses. This involves applying energy conservation equations to each component. What role does the mass balance play in optimizing thermal power plant operations? The mass balance ensures proper flow rates of water, steam, and flue gases, helping to detect leaks, optimize feedwater flow, and improve overall efficiency by ensuring mass continuity and proper mixing within the system. What are common challenges faced when performing heat and mass balance calculations in thermal power plants? Challenges include accurate measurement of flow rates and temperatures, accounting for losses and unmeasured heat transfer, and dealing with complex thermodynamic interactions, which can affect the precision of the calculations.

Related keywords: thermal power plant, heat balance, mass balance, heat transfer, thermodynamics, power plant efficiency, steam cycle, heat exchangers, energy analysis, plant performance

Read the full article online: [thermal power plant heat mass balance](#)

heat balance sheet for boiler

Understanding the Heat Balance Sheet for a Boiler

The **heat balance sheet for boiler** is an essential tool used in the analysis and optimization of a boiler's thermal efficiency. It provides a detailed account of the heat input, heat losses, and useful heat transfer within the boiler system. By comprehensively understanding the heat balance sheet, engineers and operators can identify areas where efficiency can be improved, reduce fuel consumption, and minimize environmental impact. This article delves into the concept, components, calculation methods, and significance of the heat balance sheet for boilers.

What Is a Heat Balance Sheet for a Boiler?

A heat balance sheet is a systematic representation that accounts for all heat inputs, outputs, and losses in a boiler during operation. It essentially ensures that the energy supplied to the boiler equals the energy utilized and lost, in accordance with the law of conservation of energy. The primary goal is to quantify each component's contribution to overall efficiency and pinpoint potential improvements.

Importance of Heat Balance Sheet in Boiler Operation

- Optimizes fuel consumption by identifying heat losses.
- Enhances boiler efficiency through targeted maintenance and adjustments.
- Reduces environmental pollution by minimizing unburned fuel and emissions.
- Assists in troubleshooting operational issues.
- Provides data for designing more efficient boiler systems.

Components of a Heat Balance Sheet for a Boiler

The heat balance sheet typically includes the following components:

1. Heat Input

- **Calorific value of fuel:** The energy content per unit mass or volume of fuel used.
- **Fuel consumption:** Quantity of fuel burned per hour.
- **Total heat supplied:** Calculated as fuel consumption multiplied by the calorific value.

2. Useful Heat Transfer

- **Steam generated:** Quantity and quality of steam produced.
- **Outlet water and heat transfer:** Heat transferred to the water/steam cycle.
- **Efficiency of heat transfer:** How effectively the heat is transferred to produce usable steam or hot water.

3. Heat Losses

- **Flue gases:** Heat lost with the hot gases exiting the chimney.
- **Unburned carbon:** Heat lost due to incomplete combustion.
- **Radiation and convection losses:** Heat escaping through the boiler walls and surface radiation.
- **blowdown losses:** Heat lost when blowdown water is discharged.
- **Other losses:** Includes losses due to leaks, excess air, etc.

Steps to Prepare a Heat Balance Sheet for a Boiler

Constructing a heat balance sheet involves systematic data collection and calculations. The typical

steps include:

1. Measure Fuel Consumption

Record the amount of fuel burned over a specific period, often in kg, tonnes, or cubic meters.

2. Determine Calorific Value of Fuel

Use calorimeters or manufacturer data to find the gross or net calorific value of the fuel.

3. Calculate Heat Input

Multiply fuel consumption by calorific value:

- **Heat Input (Q_{in}):** Fuel consumption $\times$ Calorific value

4. Measure Steam or Hot Water Output

Record the quantity, pressure, and temperature of steam or hot water produced.

5. Calculate Useful Heat Output

Based on the steam quality and properties, calculate the heat transferred to the working fluid.

6. Collect Flue Gas Data

Determine flue gas temperature, oxygen content, and flow rate to calculate heat carried away by flue gases.

7. Calculate Heat Losses

- **Losses with flue gases:** Using flue gas data, calculate the heat carried away.
- **Unburned carbon loss:** Estimate based on ash analysis or combustion efficiency.
- **Radiation and convection:** Use surface temperature data and heat transfer coefficients.
- **Blowdown losses:** Measure blowdown water temperature and flow rate.

8. Compile and Analyze Data

Arrange all data into a comprehensive table or chart, summing up total heat input, useful heat

output, and total losses.

Sample Heat Balance Sheet for a Boiler

Here's a simplified example illustrating the typical format of a heat balance sheet:

Component	Quantity	Unit	Calculation / Remarks
Fuel consumption	1000	kg/hr	Given
Calorific value of fuel	30,000	kJ/kg	Assumed or measured
Heat input (Q _{in})	30,000,000	kJ/hr	1000 × 30,000
Steam generated	5,000	kg/hr	Measured
Enthalpy of steam	2800	kJ/kg	At operating conditions
Useful heat output	14,000,000	kJ/hr	5,000 × 2800
Heat losses through flue gases	10,000,000	kJ/hr	Calculated from flue gas data
Other losses (radiation, convection, blowdown)	2,000,000	kJ/hr	Estimated
Total losses	12,000,000	kJ/hr	Sum of all losses

This example demonstrates how energy flows within the boiler system, highlighting areas where efficiency can be improved.

Calculating Thermal Efficiency Using the Heat Balance Sheet

The efficiency of a boiler is derived from the ratio of useful heat output to heat input:

Boiler Efficiency (%) = (Useful Heat Output / Heat Input) × 100

In the example above:

Efficiency = (14,000,000 / 30,000,000) × 100 = 46.67%

This indicates that approximately 46.67% of the energy from the fuel is converted into useful heat, with the rest lost through various mechanisms.

Factors Affecting the Heat Balance Sheet and Boiler Efficiency

- **Fuel quality:** Higher moisture content reduces efficiency.
- **Combustion process:** Incomplete combustion leads to unburned fuel losses.
- **Boiler design and maintenance:** Corrosion, scaling, and poor insulation increase losses.
- **Operating conditions:** Excess air or improper firing affects heat transfer and losses.
- **Flue gas treatment:** Proper economizers and air preheaters can recover waste heat.

Improving the Heat Balance and Boiler Efficiency

1. Regular Maintenance

- Cleaning heat transfer surfaces.

-

Heat Balance Sheet for Boiler: An In-Depth Analytical Review

In the realm of thermal engineering and process industries, boilers serve as fundamental units for generating steam, which is pivotal across various sectors such as power generation, manufacturing, and chemical processing. Ensuring the efficient operation of boilers is critical not only for optimizing energy consumption but also for reducing operational costs and minimizing environmental impact. Central to this optimization process is the concept of the heat balance sheet for boiler, a comprehensive analytical tool that helps engineers understand the thermal efficiencies and energy flows within a boiler system.

This article offers a detailed exploration of the heat balance sheet for boilers?its purpose, methodology, significance, and practical applications?aimed at professionals, researchers, and students seeking an in-depth understanding of boiler performance analysis.

Understanding the Heat Balance Sheet for Boiler

A heat balance sheet for boiler is essentially a systematic accounting of all heat inputs and outputs associated with a boiler system. It provides a quantitative assessment of how the energy supplied to the boiler is utilized, lost, or conserved. By analyzing the heat balance, engineers can identify inefficiencies, troubleshoot operational issues, and develop strategies for performance enhancement.

Purpose of the Heat Balance Sheet

- To quantify the efficiency of the boiler.
- To identify major heat losses.
- To facilitate troubleshooting and maintenance planning.
- To optimize operational parameters for better energy utilization.
- To comply with environmental and safety standards.

Fundamental Principle

The core idea behind the heat balance sheet is the conservation of energy, expressed as:

Total Heat Input = Useful Heat Output + Heat Losses + Accumulation

In steady-state operations, the accumulation term becomes negligible, simplifying the energy balance.

Components of the Heat Balance Sheet

A typical heat balance sheet for a boiler involves detailed calculations of various energy streams. These include:

1. Heat Input

- Fuel Heat Input (Q_{in}): The energy content of the fuel supplied to the boiler, calculated as:

$$Q_{in} = \text{Fuel Consumption} \times \text{Calorific Value of Fuel}$$

- Other Inputs: Auxiliary energy inputs such as electrical energy, if any.

2. Useful Heat Output

- Steam Energy (Q_{out}): The energy contained in the generated steam, determined by:

$$Q_{out} = \text{Mass of Steam (m)} \times \text{Enthalpy of Steam (h}_{steam}) - \text{Enthalpy of Feedwater (h}_{feedwater})$$

This represents the effective transfer of heat energy for process use.

3. Heat Losses

- Flue Gas Losses: Heat carried away by flue gases, calculated based on flue gas temperature and specific heat.
- Unburned Carbon Losses: Residual carbon in ash.
- Radiation and Convection Losses: Heat radiated from the boiler surface and transferred via convection.
- Leakage and Ventilation Losses: Heat lost through openings, leaks, or unnecessary ventilation.
- Other Losses: Such as moisture in fuel, incomplete combustion, etc.

4. Heat Stored or Accumulated

- Usually negligible in steady-state operation but relevant during startup or shutdown phases.

Methodology for Constructing a Heat Balance Sheet

Developing a heat balance sheet involves systematic data collection, calculations, and analysis. The process generally follows these steps:

Step 1: Data Collection

- Fuel consumption rate.
- Calorific value of fuel.
- Flue gas temperature and composition.
- Feedwater temperature and flow rate.
- Steam parameters (pressure, temperature).
- Ambient conditions.

Step 2: Calculation of Heat Inputs

- Determine the total heat supplied via fuel.
- Include auxiliary electrical or energy inputs if applicable.

Step 3: Calculation of Heat Outputs

- Calculate the heat carried away by steam.
- Determine the energy loss through flue gases and other pathways.

Step 4: Quantification of Losses

- Use specific heat formulas and temperature data to compute heat losses.
- For example, flue gas heat loss:

$$Q_{\text{loss}} = m_{\text{g}} \times C_{\text{pg}} \times (T_{\text{g}} - T_{\text{ambient}})$$

where:

- m_{g} = mass flow rate of flue gases
- C_{pg} = specific heat capacity of flue gases
- T_{g} = flue gas temperature
- T_{ambient} = ambient temperature

Step 5: Summarization and Analysis

- Tabulate all data.
- Calculate efficiencies and percentage losses.
- Identify dominant sources of inefficiency.

Interpreting the Heat Balance Sheet

The heat balance sheet provides a snapshot of boiler performance. Key metrics include:

- Thermal Efficiency:

\[

$$\eta = \frac{\text{Useful heat output}}{\text{Total heat input}} \times 100\%$$

\]

- Heat Loss Percentage:

\[

$$\text{Losses} = 100\% - \eta$$

\]

- Major Loss Contributors: Identifying which losses contribute most enables targeted improvements.

Typical Efficiency Ranges

- Modern, well-maintained boilers: 80-90%
- Older or poorly maintained boilers: 60-75%

By analyzing the heat balance sheet, operators can implement measures such as economizer installation, flue gas heat recovery, or combustion optimization to enhance efficiency.

Significance and Practical Applications

The heat balance sheet is more than an academic exercise; it's a practical tool with direct operational benefits:

- Performance Monitoring: Regular updates of the heat balance sheet enable ongoing performance assessment.
- Troubleshooting: Detecting abnormal heat losses or inefficiencies signals maintenance needs.
- Design Optimization: Informing design modifications for new boilers or retrofits.
- Energy Conservation: Identifying energy-saving opportunities reduces fuel costs and environmental footprint.
- Regulatory Compliance: Demonstrating efficient operation aligns with environmental regulations.

Challenges and Limitations

While invaluable, constructing and analyzing a heat balance sheet involves certain challenges:

- Data Accuracy: Precise measurements of fuel consumption, flue gas composition, and temperatures are essential.
- Complexity: Large systems with multiple heat streams require meticulous calculations.
- Transient Conditions: Steady-state assumptions may not always hold during startup/shutdown.
- Assumption Validity: Simplifications may overlook certain minor losses.

Despite these challenges, advancements in instrumentation and data acquisition systems have made heat balance analysis more accessible and accurate.

Advancements and Future Trends

Recent developments aim to improve heat balance analysis, including:

- Automated Data Collection: Use of sensors and IoT devices for real-time monitoring.
- Computational Tools: Advanced software for simulation and detailed analysis.
- Integration with Control Systems: Enabling dynamic adjustments based on heat balance insights.
- Environmental Considerations: Incorporation of emissions and pollution control into heat efficiency analysis.

These trends promise more precise, proactive, and sustainable boiler operation management.

Conclusion

The heat balance sheet for boiler remains a cornerstone in thermal performance evaluation, offering a clear and quantifiable picture of energy flows within boiler systems. By diligently constructing and analyzing the heat balance sheet, engineers and operators can unlock significant efficiency gains, extend equipment lifespan, and contribute to sustainable industrial practices. As technology advances, the integration of real-time data and automation will further enhance the utility of heat balance analysis, making it an indispensable tool in modern thermal management.

In essence, mastering the principles and application of the heat balance sheet empowers stakeholders to operate boilers more intelligently, efficiently, and responsibly?fundamental objectives in today?s energy-conscious world.

Question What is a heat balance sheet for a boiler? A heat balance sheet for a boiler is a detailed record that accounts for all heat inputs, outputs, and losses within the boiler system, used to analyze efficiency and performance. **Why is a heat balance sheet important for boiler operation?** It helps in identifying energy losses, optimizing efficiency, and ensuring safe and economical operation by providing a comprehensive view of heat flow within the boiler. **What are the main components of a heat balance sheet for a boiler?** The main components include heat input from fuel, heat losses (radiation, convection, unburned carbon), useful heat transferred to the steam, and heat losses through flue gases and blowdown. **How do you calculate the heat input in a boiler heat balance sheet?** Heat input is calculated based on the calorific value of the fuel and the amount of fuel consumed, typically using the formula: $\text{Heat Input} = \text{Fuel consumption} \times \text{Calorific value of fuel}$. **What are common heat losses considered in a boiler heat balance sheet?** Common heat losses include flue gas losses, radiation losses from the boiler surface, unburned carbon in ash, blowdown losses, and other miscellaneous losses like soot and moisture evaporation. **How can the heat balance sheet be used to improve boiler efficiency?** By analyzing the heat losses and inefficiencies detailed in the sheet, operators can implement measures such as better insulation, improved combustion, or waste heat recovery to enhance overall efficiency. **What is the typical efficiency range of a boiler as determined from the heat balance sheet?** The efficiency of a boiler, as derived from the heat balance sheet, generally ranges from 75% to 90%, depending on design, maintenance, and operating conditions. **Can a heat balance sheet help in troubleshooting boiler issues?** Yes, it can identify abnormal heat losses or inefficiencies, helping technicians pinpoint problems such as poor combustion, leaks, or scaling that affect boiler performance. **What data is required to prepare a heat balance sheet for a boiler?** Data needed includes fuel consumption, fuel calorific value, flue gas temperature and composition, steam output, feedwater temperature, and ash or losses in other forms. **How often should a heat balance sheet be prepared for a boiler?** It is recommended to prepare a heat balance sheet periodically, such as monthly or quarterly, to monitor performance trends and ensure efficient operation.

Related keywords: boiler heat balance, boiler efficiency, heat loss in boiler, boiler combustion

analysis, heat transfer in boiler, boiler performance, flue gas analysis, energy balance boiler, boiler heat input, boiler heat output

Read the full article online: [Heat Balance Sheet For Boiler](#)

calculation deaerator balance

Calculation of Deaerator Balance: An In-Depth Guide

Calculation deaerator balance is a fundamental process in the design, operation, and troubleshooting of deaerators within steam systems. Deaerators are crucial equipment used to remove dissolved gases, primarily oxygen and carbon dioxide, from feedwater to prevent corrosion in downstream boiler and piping systems. Proper calculation of the deaerator balance ensures optimal removal of these gases, efficient operation, and minimal energy consumption. This article provides a comprehensive overview of the principles, methods, and steps involved in calculating the deaerator balance, including the mass and energy balances, typical calculations, and practical considerations.

Understanding the Role of a Deaerator

Function and Importance

Deaerators are designed to eliminate dissolved gases from boiler feedwater, which can cause severe corrosion and reduce system efficiency. They operate by heating the feedwater and exposing it to a controlled environment where gases are released and vented away. Proper operation hinges on maintaining a precise balance of mass and energy within the deaerator to ensure effective gas removal while conserving energy.

Types of Deaerators

- Tray Deaerators: Use trays to contact feedwater with steam, promoting gas release.
- Spray Deaerators: Use spray nozzles to atomize feedwater, enhancing heat transfer and gas removal.
- Combination Units: Combine features of both for optimized performance.

Fundamental Principles of Deaerator Balance Calculation

Mass Balance

The mass balance involves accounting for all incoming and outgoing streams of water and gases. It ensures that the amount of feedwater, vented gases, and makeup water are accurately considered.

Basic mass balance equation:

$$\text{Inflow} = \text{Outflow} + \text{Accumulation}$$

For steady-state operation, accumulation is zero, simplifying the calculations.

Energy Balance

The energy balance accounts for the heat transfer processes within the deaerator, including heating of feedwater, vaporization, and venting. It ensures that the temperature and pressure conditions are maintained for optimal gas removal.

Basic energy balance equation:

$$\text{Energy In} = \text{Energy Out} + \text{Energy Losses}$$

This involves calculating the enthalpy of incoming water and steam, as well as the heat carried away by vented gases.

Step-by-Step Calculation of Deaerator Balance

1. Data Collection and Input Parameters

Gather all necessary data:

- Feedwater flow rate (Q_{fw})
- Feedwater temperature (T_{fw})
- Feedwater pressure (P_{fw})
- Steam inlet parameters (pressure, temperature, flow rate)
- Vent gas flow rate and composition
- Make-up water flow (Q_m)
- Operating pressure and temperature of deaerator (P_d, T_d)

2. Calculating Dissolved Gas Content

Use Henry's law or saturation tables to determine the initial dissolved oxygen (DO) and carbon dioxide (CO₂) levels in the feedwater. Standard concentrations are often expressed in ppm.

Example:

$$\text{DO}_{\text{initial}} = \text{value from feedwater analysis}$$

3. Estimating Gas Removal Efficiency

Determine the desired removal efficiency, typically expressed as a percentage:

- For oxygen: 98-99%
- For carbon dioxide: 95-98%

The removal efficiency depends on the temperature, pressure, and contact time within the deaerator.

4. Calculating Gas Removal Rates

Using the initial gas concentrations and the removal efficiency:

$$\text{Gas removed} = \text{Initial dissolved gas} \times \text{Efficiency}$$

The vent gas flow rate (Q_{vent}) can then be estimated:

$$Q_{\text{vent}} = \frac{\text{Gas removed} \times \text{molecular weight}}{\text{gas density}}$$

5. Heat Balance Calculations

Calculate the heat required to raise feedwater to the deaerator temperature:

$$Q_{\text{heat}} = Q_{\text{fw}} \times (h_{\text{T}} - h_{\text{T}_{\text{in}}})$$

Where:

- (h_{T}): Enthalpy at deaerator temperature
- ($h_{\text{T}_{\text{in}}}$): Enthalpy of incoming feedwater

Determine the heat supplied by steam:

$$Q_{\text{steam}} = m_{\text{steam}} \times (h_{\text{steam}} - h_{\text{condensate}})$$

Match the heat input with the heat needed to raise feedwater temperature and vaporize part of the water, considering losses.

6. Calculating Vent and Blowdown Flows

- Vented gases: Remove gases along with non-condensable gases.
- Blowdown: Periodic removal of concentrated impurities; its flow rate impacts the overall mass balance.

Calculate blowdown rate based on boiler operation and water quality standards.

7. Final Balancing and Verification

Ensure that the sum of all inflows equals outflows:

- Total feedwater + makeup water = total vented gases + blowdown + condensate return

Verify that the calculated dissolved gas removal aligns with system requirements and operational constraints.

Practical Considerations in Deaerator Balance Calculation

Operating Conditions

- Pressure and temperature significantly influence gas solubility.
- Higher temperatures reduce gas solubility, improving removal efficiency.

Gas Laws and Solubility Data

Use Henry's law and published solubility tables for accurate estimation:

- Gas solubility decreases with increasing temperature.
- Partial pressures of gases influence removal rates.

Efficiency and Performance Optimization

- Proper tray or spray design enhances contact.
- Adequate venting ensures removal of gases.
- Regular monitoring of dissolved oxygen levels maintains system integrity.

Common Challenges and Troubleshooting

- Insufficient venting leads to oxygen carryover.
- Overheating can cause corrosion.
- Improper balance causes inefficiency and increased energy consumption.

Conclusion

Accurate calculation of the deaerator balance is essential for efficient and reliable operation of steam systems. It involves comprehensive mass and energy balances, understanding of thermodynamic principles, and practical considerations related to system design and operation. By systematically following the steps?gathering data, estimating gas removal, performing heat calculations, and verifying inflow-outflow balance?engineers can optimize deaerator performance, minimize energy costs, and extend equipment lifespan. Properly calculated and maintained deaerator balances are vital for preventing corrosion, ensuring water quality, and achieving overall plant efficiency.

Calculation of deaerator balance is a critical aspect of boiler feedwater system management, ensuring that the deaerator operates efficiently, reliably, and safely. Proper deaerator balance involves understanding and optimizing the inputs and outputs of the deaerator to maintain desired water quality, prevent corrosion, and maximize system performance. Whether you're an engineer, operator, or maintenance professional, grasping the fundamentals of deaerator balance calculations is essential for effective plant operation and troubleshooting.

Introduction to Deaerator Balance

A deaerator is a device used to remove dissolved gases?primarily oxygen and carbon dioxide?from boiler feedwater. These gases can cause corrosion inside the boiler and associated piping, leading to reduced equipment lifespan and increased maintenance costs. The deaerator achieves this by heating the feedwater and stripping gases through a combination of temperature control, steam sparging, and venting.

Achieving a proper deaerator balance means ensuring that the amount of gases removed aligns with the incoming water quality, steam input, venting capacity, and other operational parameters. An imbalance can lead to inefficient deaeration, higher oxygen levels in the feedwater, or unnecessary steam and vent losses.

Fundamental Principles of Deaerator Balance

Before diving into calculations, it's important to understand the key components involved:

- Inflow (Feedwater): The water entering the deaerator, which contains dissolved gases.
- Steam Input: The steam used to heat the water and strip gases.
- Venting (Vent): The removal of gases and non-condensable impurities.
- Outflow (Deaerated Water): The treated water sent to the boiler.

The balance involves matching these inputs and outputs to ensure efficient operation, minimal losses, and water quality standards.

Key Parameters in Deaerator Balance

To perform a comprehensive calculation, you need to know or measure:

- Feedwater flow rate (Q_{fw}): Typically in kg/hr or m³/hr.
- Inlet water temperature (T_{in}): Usually in °C.
- Inlet dissolved oxygen (DO_{in}): in ppm or mg/L.
- Outlet water temperature (T_{out}): Usually close to saturation temperature at operating pressure.
- Steam consumption (Q_{steam}): in kg/hr.
- Vapor vent rate (Q_{vent}): in kg/hr of gases vented.
- Gases in water: Mainly oxygen and carbon dioxide, which need to be reduced to acceptable levels.

Step-by-Step Guide to Calculating Deaerator Balance

- Determine the Inlet Dissolved Gases

The initial step is to assess the amount of dissolved oxygen (DO) and CO₂ in the incoming water:

- Dissolved Oxygen (DO):

DO_{in} (mg/L) can be measured directly or estimated via water quality analysis.

- Dissolved Carbon Dioxide (CO₂):

Similarly measured or estimated.

- Calculate the Gas Load in the Incoming Water

Convert dissolved gases into total gas load:

- Oxygen load (mg/L):

$$O_2_load = DO_in \times Q_fw$$

- CO₂ load (mg/L):

$$CO_2_load = CO_2_in \times Q_fw$$

Total gas load is then:

$$Total\ gas\ (mg) = O_2_load + CO_2_load$$

- Estimate the Gas Removal Efficiency

Deaerators typically aim to reduce DO to less than 10 ppb (parts per billion) and CO₂ to minimal levels. The efficiency depends on:

- Temperature of the water
- Contact time
- Venting capacity
- Steam purity

Assuming a target reduction, the amount of gases removed must match the incoming load minus the residual gases.

- Calculate the Steam Requirement for Gas Stripping

The stripping of gases requires heating and steam:

- Heat transfer:

To heat the water from inlet to saturation temperature.

- Steam consumption:

The amount of steam needed depends on:

- The heat needed to raise water temperature:

$$Q_{\text{heat}} = Q_{\text{fw}} C_p (T_{\text{sat}} - T_{\text{in}})$$

where C_p is specific heat of water (~4.18 kJ/kg·K).

- The latent heat to vaporize gases:

Gases are removed via venting, so the vent rate must carry the gases away.

- Steam for stripping:

The amount of steam required to effectively strip gases is generally estimated based on empirical data or plant-specific design parameters, often expressed as:

$$Q_{\text{steam}} = \text{Gas removal rate steam-to-gas ratio}$$

Typical steam-to-gas ratios are in the range of 0.2 to 0.5 kg steam per kg of gases removed.

- Determine Venting Rate

The vent rate (Q_{vent}) is directly related to the gas removal:

$$Q_{\text{vent}} = \text{Gas removal rate (kg/hour)}$$

Where:

- Gas removal rate depends on the initial dissolved gas content and the efficiency of the deaerator.

- Establish the Balance Equation

Putting it all together, the deaerator balance can be summarized as:

- Input side:

- Water inflow: Q_{fw}

- Gas load: from dissolved gases

- Output side:

- Deaerated water: Q_{fw} (minus minor losses)

- Vent gases: Q_{vent}

- Steam input: Q_{steam}

Balance equation:

$Q_{vent} = \text{Gas load in feedwater} - \text{residual gases in outflow}$

and

$Q_{steam} = \text{heat required to raise water temperature} + \text{energy to strip gases}$

Practical Example

Suppose:

- Feedwater flow rate: 10,000 kg/hr

- Inlet DO: 8 mg/L

- Inlet temperature: 25°C

- Saturation temperature at operating pressure: 120°C

- Target residual DO:

Step 1: Calculate initial oxygen load:

$$O_2 \text{ load} = 8 \text{ mg/L } (Q_{fw} \text{ in L/hr})$$

Since 1 kg of water = 1 L, then:

$$Q_{fw} \text{ in L/hr} = 10,000 \text{ kg/hr}$$

$$O_2 \text{ load} = 8 \text{ mg/L } 10,000 \text{ L/hr} = 80,000 \text{ mg/hr} = 80 \text{ g/hr}$$

Step 2: Convert to molar quantities and determine gases to be vented.

- Molar mass of O_2 = 32 g/mol

- Moles of oxygen per hour:

$$80 \text{ g/hr} \div 32 \text{ g/mol} = 2.5 \text{ mol/hr}$$

- Since gases are vented, the vent rate of oxygen is approximately 2.5 mol/hr, or about 80 g/hr.

Step 3: Determine steam requirement for stripping:

- Using an empirical steam-to-gas ratio of 0.3:

$$Q_{steam} = 0.3 \times 80 \text{ g/hr} = 24 \text{ g/hr}$$

- Convert to kg/hr:

$$24 \text{ g/hr} \div 1000 = 0.024 \text{ kg/hr}$$

This indicates a minimal steam requirement for venting gases, but in practice, the actual steam used is higher due to heat transfer needs.

Step 4: Finalize the balance:

- Steam supplied: based on heat needed to raise water to saturation temperature plus gas stripping energy.

- Vent gases: approximately matching the initial oxygen load, with adjustments based on efficiency.

Tips for Accurate Deaerator Balance Calculation

- Regular Sampling: Measure inlet and outlet water quality regularly to determine actual gas loads.

- Empirical Data: Use plant-specific data and experience to refine steam-to-gas ratios.

- Monitoring Instruments: Employ dissolved oxygen meters and vent gas analyzers for real-time data.

- Simulation Software: Utilize process simulation tools for complex calculations and scenario analysis.

- Maintenance: Keep vents, heat exchangers, and controls in optimal condition to ensure accurate balances.

Conclusion

Calculation of deaerator balance is a vital process that ensures the effective removal of dissolved gases from boiler feedwater while optimizing steam and vent usage. It involves understanding the relationship between incoming water quality, heat transfer, gas stripping efficiencies, and venting capacity. By systematically analyzing each component and applying fundamental principles, plant engineers and operators can maintain a well-balanced deaerator, leading to improved system reliability, reduced corrosion, and energy savings.

A thorough grasp of these calculations not only enhances operational efficiency but also supports proactive maintenance and troubleshooting efforts. Whether for new plant design, routine operation, or troubleshooting, mastering deaerator balance calculations is a cornerstone of effective boiler feedwater management.

Question What is the purpose of performing a deaerator balance calculation in a power plant? A deaerator balance calculation helps determine the proper feedwater and steam flow rates, ensuring efficient oxygen removal, minimizing corrosion, and maintaining optimal deaerator operation within the system. Which key parameters are needed to perform a deaerator balance calculation? Essential parameters include feedwater flow rate, steam flow rate, oxygen content levels, inlet and outlet water temperatures, pressure, and the oxygen removal efficiency of the deaerator. How do you account for oxygen removal efficiency in a deaerator balance calculation?

Oxygen removal efficiency is factored into the calculation by adjusting the oxygen content reduction from inlet to outlet, typically expressed as a percentage, to determine the required steam flow and feedwater conditions for desired oxygen levels. What role does the vent and drain flow play in deaerator balance calculations? Vent and drain flows are critical as they represent the removal of non-condensable gases and impurities, affecting the overall mass balance and oxygen removal efficiency calculations. Can you explain the basic steps involved in calculating a deaerator balance? Yes, the steps include: 1) measuring inlet and outlet water and steam flows, 2) calculating the oxygen content reduction, 3) accounting for vent and drain flows, and 4) balancing the mass and oxygen removal to determine the required steam and water flows. What are common challenges faced when performing a deaerator balance calculation? Challenges include accurate measurement of flows and oxygen levels, variability in operating conditions, and ensuring the model accounts for all non-condensable gases and impurities accurately. How does the pressure in the deaerator affect the balance calculation? Deaerator pressure influences the solubility of gases and the efficiency of oxygen removal, thus affecting the required steam flow and the overall mass balance calculations. Why is it important to regularly update deaerator balance calculations? Regular updates ensure the system operates efficiently, prevents corrosion, and adapts to changes in operating conditions, feedwater quality, or equipment performance. What software or tools are commonly used for deaerator balance calculations? Tools such as process simulation software (e.g., HYSYS, Aspen Plus), Excel spreadsheets, and plant-specific control systems are commonly used to perform and verify deaerator balance calculations. How can deviations in deaerator balance calculations impact plant performance? Deviations can lead to inadequate oxygen removal, increased corrosion, reduced efficiency, and potential equipment damage, highlighting the importance of accurate and regular balance assessments.

Related keywords: deaerator, drum, feedwater, venting, oxygen removal, blowdown, pressure, temperature, steam, tank

Read the full article online: [calculation deaerator balance](#)